



Wave

Product Description

WAVE is a desktop trackball using durable optical technology for precise control of on-screen elements.

With silky-smooth ball movement, a large, stable footprint and low profile, the **WAVE** is a flexible device suitable for computer users with a variety of fine and gross motor skills.

Robustly constructed with no mechanical wearing parts the **WAVE** is maintenance free and will give years of reliable service.

Features

- Robust construction and ergonomic design
- Durable optical technology with no mechanical wearing parts
- Precise tracking and cursor control
- Large free-running ball requiring only the lightest touch
- Silky-smooth ball movement
- Large footprint for stability
- Low profile providing a natural hand rest for comfortable operation
- Left/Right and Drag Lock buttons
- Color-coded buttons mounted sub-flush to prevent accidental activation
- External Switch Jacks to operate Left/Right click
- Auto detecting PS2 and USB protocols
- Easy 'plug and play' installation (no additional drivers required)
- PC and Mac compatible

Compatibility

WAVE works with PS2 and USB compatible computers including the majority of Personal Computers (PCs) and Apple Macintosh computers.

Installation

Ensure your computer is fully turned-off and not just in sleep mode. Locate the relevant PS2 or USB port on your computer and plug-in your **WAVE** (if you are using the PS2 port on your computer you will need the USB-PS2 adaptor supplied).

Switch on your computer and **WAVE** automatically configures itself to either PS2 or USB operation and is ready to use. No driver files are required.

NOTE: Adjust the tracking speed via your computer's Control Panel (Win) or System Preferences (Mac)

Maintenance

Your **WAVE** has no user serviceable parts. If repair is necessary the unit should be returned to AbleNet, Inc. or an authorized distributor.

Warranty

AbleNet offers a limited, 24-month warranty on the **WAVE** trackball. For full warranty details, visit www.ablenetinc.com.



AbleNet, Inc.
Minneapolis/St. Paul, MN
800-322-0956 (U.S. & Canada)
651-294-2200 (Outside U.S.)
www.ablenetinc.com